

18 GA Power Flanger Parts List

<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
27-001	Gear Housing	1
27-002	Gasket	1
27-003	Housing Cover - Casting	1
28-001	Forming Head	1
27-005	Dial	1
27-006	Vertical Shaft	1
27-007	Horizontal Shaft	1
27-008	Worm Gear	1
27-009	Worm Gear	1
27-010	15 Tooth Gear	2
10-001	Bearing B - 108	2
11-010	Race IR - 316	1
27-024	Thrust Bearing # 605 - Nice	1
14-021	Bearing B 1412	2
27-011	Bronze Bushing P 64 - 12	2
27-012	Oil Seal CR - 6229	1
11-012	Guide Roll Holder Assembly	1
11-014	Roll Guide Holder Assembly	1
11-016	Guide Roll Holder Assembly	1
27-025	Gear Cover Assembly	1
27-023	Cabinet Assembly	1
10-031	Label - Manufacturer	1
10-032	Motor	1
10-038	Starter GE 5981 - 8	1
10-040	Label- Osha	1
10-042	Warning Label	1
27-019	Pulley AZ 50	1
27-020	Pulley AZ 30	1
27-021	"V" Belt 4L560	1
27-022	Freezer Plug Dorman P14C	1
14-048	Motor Clamp Assembly	4
28-037	Knurled Roll	1
28-038	Plain Roll	1
27-039	Lifter Button	1